



SURGICAL CREAM SERUM ASPECT

This cream is formulated with:

MATRIGENICS.14 G: rich in Wakamic Ester, this new active ingredient reactivates genes that have gone to sleep in order to restructure the Extracellular Matrix.

NEUROLIGHT.61 G: significantly reduces the size and the pigmentation of dark spots by inhibiting cellular stress molecules and the action of Substance P.

PHORMISKIN BIOPROTECH G: delays cutaneous senescence for a visibly younger and brighter skin.

Product Aspect

White glitter bi-gel

Product Properties

pH = 6.50 ± 0.3. Stable one month at 40°C and 55°C

Operating Method

- Prepare A in deflocculating. Check that the mixture is homogeneous and clear
- Heat the water to 70°C; disperse Carbopol into it under emulsifier 1500 rpm during 15 min
- Add the Elestab CPN. Mix during minutes. Cool down to around 35°C
- Then, add the mixture C under emulsifier 2000 rpm during 10 min
- Neutralize with D under emulsifier 2000 rpm during 10 min
- Slowly add A into B under emulsifier 2500 rpm, then let shake in these conditions during 15 min
- Add E

Formula

Phase	Raw material / Trade name	INCI Name	%
A	EMULFREE CBG (1)	Isostearyl Alcohol & Butylene Glycol Cocoate & Ethylcellulose	4
	CRODAMOL GTCC / MIGLYOL 812 / WAGLINOL (2)	Caprylic/Capric Triglyceride	3
	DPPG CG (1)	Propylene Glycol Dipelargonate	3
	LEXFEEL D5 (3)	Neopentyl Glycol Diheptanoate & Isododecane	4
	PHENOXYETHANOL (4)	Phenoxyethanol	0,8
B	DEMINEERALIZED WATER	Aqua	70,48
	CARBOPOL ETD 2020 (5)	Acrylates/C10-30 Alkyl Acrylate Crosspolymer	0,3
B'	ELESTAB CPN (6)	Chlorphenesin	0,27
C	BIDISTILLED GLYCERIN CODEX (7)	Glycerin	7,4
	XANTHAN GUM (8)	Xanthan Gum	0,2
D	SODA (SOLUTION 5 N) (9)	Aqua & Sodium Hydroxide	0,45
E	SYMDIOL 68 (10)	Caprylyl Glycol & 1,2-Hexanediol	0,5
	FRAGRANCE VELVET PETAL 0828225 (11)	Fragrance	0,1
	MATRIGENICS 14 G (12)	Glycerin & Aqua & Undaria Pinnatifida Extract	2
	NEUROLIGHT 61 G (12)	Glycerin & Aqua & Pancreaticum Maritimum Extract	1,5
	PHORMISKIN BIOPROTECH G (12)	Glycerin & Maris Aqua	2

Formulation Code: 1464A.02